















3D Chassis



On top of the classis two-track model, we want to build a 3D-chassis that can tilt in two directions (roll and pitch)

- We need a conversion interface from 2D to 3D mechanics.
- We need to model the balancing behavior.

© Dirk Zimmer, December 2014, Slide 9

From 2D to 3D model PlanarToMultiBody Let us look at the interface from 2D to 3D: Frame a frame a; MB.Interfaces.Frame_b frame_b; protected SI.Force fz "Normal Force"; SI.Force f0[3] "Force vector"; equation frame a.x = frame b.r 0[1]; • We prescribe the position... frame_a.y = frame_b.r_0[2]; 0 = frame b.r 0[3]; frame_b.R = · ...and the orientation MB.Frames.planarRotation({0,0,1}, -frame_a.phi, -der(frame_a.phi)); f0 = {frame_a.fx, frame_a.fy, fz}; f0*frame_b.R.T + frame_b.f = zeros(3); -frame_a.t + frame_b.t[3] = 0; Connections.root(frame_b.R); end PlanarToMultiBody © Dirk Zimmer, December 2014, Slide 1

From 2D to 3D model PlanarToMultiBody Let us look at the interface from 2D to 3D: Frame_a frame_a; MB.Interfaces.Frame b frame b; SI.Force fz "Normal Force"; SI.Force f0[3] "Force vector"; equation frame_a.x = frame_b.r_0[1]; • From 3D perspective this frame_a.y = frame_b.r_0[2]; element is like a joint with 3 0 = frame_b.r_0[3]; degrees of freedom. frame b.R = MB.Frames.planarRotation({0,0,1}, -frame_a.phi, -der(frame_a.phi));

f0 = {frame_a.fx, frame_a.fy, fz};

Connections.root(frame_b.R);
end PlanarToMultiBody

f0*frame_b.R.T + frame_b.f = zeros(3);
-frame_a.t + frame_b.t[3] = 0;

© Dirk Zimmer, December 2014, Slide 1

Or alternatively, the "joint"

constraints by resticting the motion to a single plane.

establishes 3 holonmic

From 2D to 3D model PlanarToMultiBody Let us look at the interface from 2D to 3D: Frame a frame a; MB.Interfaces.Frame_b frame_b; protected SI.Force fz "Normal Force"; SI.Force f0[3] "Force vector"; equation frame a.x = frame b.r 0[1]; · The force vector is frame_a.y = frame_b.r_0[2]; composed and resolved 0 = frame_b.r_0[3]; w.r.t. to the body system in frame_b.R = MB.Frames.planarRotation({0,0,1}, order to formulate the -frame_a.phi, -der(frame_a.phi)); balance equation f0 = {frame_a.fx, frame_a.fy, fz}; • There is no need to frame_b.R.T*f0 + frame_b.f = zeros(3); $-frame_a.t + frame_b.t[3] = 0;$ transform the torque since the torque-vector points in Connections.root(frame_b.R); direction of the rotation end PlanarToMultiBody axis. © Dirk Zimmer, December 2014, Slide 1











